

EXPLODED VIEW & PARTS LISTING
T15 METAL
Rubber-Fitted
PARTS LISTING

Item	Description	Qty	T15/ AAAAB Part No.	T15/ AAAAD Part No.	T15/ WWAAB Part No.
1	Air Valve Assy¹	1	15-2000-07	15-2080-07	15-2000-07
2	Screen	1	08-2500-07	08-2500-07	08-2500-07
3	End Cap W/Guide	1	15-2300-23	15-2300-23	15-2300-23
4	End Cap W/O Guide	1	15-2330-23	15-2330-23	15-2330-23
5	Retaining Ring	2	15-2650-03	15-2650-03	15-2650-03
6	End Cap O-Ring	2	15-2390-52	15-2390-52	15-2390-52
7	Oil Bottle ²	1	N/A	15-2850-01	N/A
8	Pipe Plug	1	N/A	08-7000-07	N/A
9	Capillary Rod Assy	1	N/A	15-2900-99	N/A
10	Gasket, Air Valve	1	15-2600-52	15-2600-52	15-2600-52
11	Screw, SHC, 5/16-18 x 2 1/4	4	08-6000-08	08-6000-08	08-6000-08
12	Center Block ³	1	15-3100-01-225	15-3100-01-225	15-3100-01-225
13	Shaft Seal Ring	7	15-3210-55-225	15-3210-55-225	15-3210-55-225
14	Gasket, Center Block	2	15-3520-52	15-3520-52	15-3520-52
15	Shaft	1	15-3800-09-07	15-3800-09-07	15-3800-09-07
16	Chamber, Air	2	15-3650-01	15-3650-01	15-3650-01
17	Screw, SFCHC, 3/8-16 x 4	4	15-6200-08	15-6200-08	15-6200-08
18	Nut, Cone, 3/8-16	4	08-6550-08	08-6550-08	08-6550-08
19	Washer, Inner Piston Backup	2	15-6850-08	15-6850-08	15-6850-08
20	Piston, Inner	2	15-3700-01	15-3700-01	15-3700-01
21	Screw, HHC, 3/8-16 x 1 1/8 ⁴	12	15-6130-08	15-6130-08	15-6130-08
	Washer, Flat 3/8 (Not shown)	12	15-6740-08-50	15-6740-08-50	15-6740-08-50
22	Diaphragm, Primary	2	*	*	*
23	Piston, Outer	2	15-4550-01	15-4550-01	15-4550-02
24	Chamber, Liquid	2	15-5000-01	15-5000-01	15-5000-02
25	Manifold, Discharge	1	15-5020-01	15-5020-01	15-5020-02
26	Manifold, Inlet	1	15-5080-01	15-5080-01	15-5080-02
27	Valve Ball	4	*	*	*
28	Valve Seat	4	*	*	*
29	Clamp Band Assy, Small ⁵	4	15-7100-08	15-7100-08	15-7100-08
30	Carriage Bolt, 3/8-16 x 2 1/4	8	15-6050-08	15-6050-08	15-6050-08
31	Nut, Heavy Hex, 3/8-16	8	08-6450-08	08-6450-08	08-6450-08
32	Clamp Band Assy, Large ⁶	2	15-7300-08	15-7300-08	15-7300-08
33	Screw, HHC, 1/2-13 x 3 1/2	4	15-6120-08	15-6120-08	15-6120-08
34	Nut, Hex, 1/2-13	4	15-6420-08	15-6420-08	15-6420-08
	Muffler (Not shown) ⁷	1	15-3510-99	15-3510-99	15-3510-99

*Refer to corresponding elastomer chart in Section 10.

¹Air valve assy (15-2000-07) includes items 2 thru 6. Air valve assy (15-2080-07) includes items 2 thru 9.

²Oil Bottle (15-2850-01) includes item 8.

³Center block (15-3100-01-225) includes item 13.

⁴Inner Piston screw (15-6130-08) utilizes 3/8" washer (15-6740-08-50)

⁵Small Clamp band assy (15-7100-08) includes items 30 and 31.

⁶Large clamp band assy (15-7300-08) includes items 33 and 34.

⁷Muffler (15-3510-99) includes 45 deg. muffler connector (15-3250-08)

All boldface items are primary wear parts.

EXPLODED VIEW & PARTS LISTING

T15 METAL

Rubber-Fitted

EXPLODED VIEW

